

Error displayed	Solution	
E01	* Close the door.	
E02	<ul style="list-style-type: none"> <li>* Make sure the source water faucet is turned on.</li> <li>* Check the water pressure.</li> <li>* Make sure the water source hose is not frozen.</li> <li>* Make sure the water intake hose is not bent.</li> <li>* Make sure the filter on the water intake hose is not clogged.</li> <li>* Check the end of the drain hose is too low.</li> </ul>	
E03	<ul style="list-style-type: none"> <li>* Clean the debris filter.</li> <li>* Make sure the drainage hose is installed correctly.</li> </ul>	
E04	* The water overfills. It can disappear automatically, otherwise close the water tap, unplug the power plug, call for service.	
E05 E06	* Motor fault.	Unplug the power plug.
E07 E08	* Heater or temperature sensor fault.	Call for service.

Erreur affichée	Solution	
E01	* Fermez la porte	
E02	<ul style="list-style-type: none"> <li>* Assurez vous que le robinet d'arrivée d'eau est ouvert.</li> <li>* Vérifiez la pression d'eau.</li> <li>* Assurez vous que le flexible d'alimentation en eau n'est pas gelé.</li> <li>* Assurez vous que le flexible d'alimentation en eau n'est pas plié.</li> <li>* Assurez vous que le filtre du flexible d'alimentation en eau n'est pas bouché.</li> <li>* Vérifiez que l'extrémité du tuyau de vidange n'est pas trop basse.</li> </ul>	
E03	<ul style="list-style-type: none"> <li>* Nettoyez le filtre à débris.</li> <li>* Assurez vous que le tuyau de vidange est installé correctement.</li> </ul>	
E04	* L'eau déborde. Cela peut disparaître automatiquement, sinon fermer le robinet d'eau, débrancher l'appareil, et appeler un professionnel.	
E05 E06	* Défaut du moteur.	Débrancher l'appareil, faire appel à des Professionnels.
E07 E08	* Défaut du chauffage ou de la sonde de température.	