

Error displayed	Solution	
E01	* Close the door.	
E02	<ul style="list-style-type: none"> * Make sure the source water faucet is turned on. * Check the water pressure. * Make sure the water source hose is not frozen. * Make sure the water intake hose is not bent. * Make sure the filter on the water intake hose is not clogged. * Check the end of the drain hose is too low. 	
E03	<ul style="list-style-type: none"> * Clean the debris filter. * Make sure the drainage hose is installed correctly. 	
E04	* The water overfills. It can disappear automatically, otherwise close the water tap, unplug the power plug, call for service.	
E05 E06	* Motor fault.	Unplug the power plug.
E07 E08	* Heater or temperature sensor fault.	Call for service.

Erreur affichée	Solution	
E01	* Fermez la porte	
E02	<ul style="list-style-type: none"> * Assurez vous que le robinet d'arrivée d'eau est ouvert. * Vérifiez la pression d'eau. * Assurez vous que le flexible d'alimentation en eau n'est pas gelé. * Assurez vous que le flexible d'alimentation en eau n'est pas plié. * Assurez vous que le filtre du flexible d'alimentation en eau n'est pas bouché. * Vérifiez que l'extrémité du tuyau de vidange n'est pas trop basse. 	
E03	<ul style="list-style-type: none"> * Nettoyez le filtre à débris. * Assurez vous que le tuyau de vidange est installé correctement. 	
E04	*L'eau déborde. Cela peut disparaître automatiquement, sinon fermer le robinet d'eau, débrancher l'appareil, et appeler un professionnel.	
E05 E06	* Défaut du moteur.	Débrancher l'appareil, faire appel à des Professionnels.
E07 E08	* Défaut du chauffage ou de la sonde de température.	