




TS	TEMPERATURE SENSOR
NTC	NTC SENSOR
FM	FM SENSOR
SI	SI SENSOR
KN1	...
KN2	...
KN3	...
KN4	...
KN5	...
KN6	...
KN7	...
KN8	...
KN9	...
KN10	...
KN11	...
KN12	...
KN13	...
KN14	...
KN15	...
KN16	...
KN17	...
KN18	...
KN19	...