

C9S0DF003X

This diagram shows the exploded perspective view of the upper part of the oven assembly. It includes the upper front panel (1.1) with a control knob, the main oven body (1.2) with four burners, and the upper support rail (1.3). The lower support rail (1.4) is also shown. The exploded view illustrates the assembly relationship between these components, with callouts 1.5 and 1.6 indicating the location of the screws used for assembly.



