



WSZ085

\* Check the Rating Model No.




For model  
MC-3088NBC  
MC-3088IXC

\* Check the Rating Model No.

For model  
MC-3088NBC / 01  
MC-3088IXC / 01



\* Check the Rating Model No.



Button Head  
(Torx style 2)

56411A

WTT021

56322A

WSZ185

50FZZA

54620A

56201A

WTT028

568772

WTT021

55900A

54974S

WTT034

56549F

56912B

WSZ002

50CZZH

56324A

54810C

WTT028

56851C

WSZ002

WSZ002

55262A

WTT021

535042

36549C

56208A

55238A

535041

WNZ015

WTT021

54975G

55300S

WTT021

WNZ015

WNZ015

54810S

55900C

WTT021

WTT021

WNH200

WWS005

55900C

