










*If you need to replace 230C,
please also replace 212H.










3-2. Case Part







Model : LSR100



※ When you replace a part without a code, you need to replace it with a part having upper level code.
- 120A, 120B, 332C




R Room Rail



F Room Rail

144A



144B

