







07 4445
V01
09 6325
V02







Pos.	V01,V02	V03	
	Danfoss	Danfoss	
	TLY4K	TLES4K	
1	14 1821	14 1663	
2			
3	15 1055	15 1055	
4			
5	15 0760	15 0760	
6	15 1072	15 1072	
7	16 9319	16 9319	
8	26 4879	26 4879	
9	050166	050166	
10			
11	26 4878	26 4878	
12	05 6008	05 6008	