



VUE A




- 1 - CD/DVD (MANUAL)
- 2 - Key
- 3 - Pen
- 4 - Battery
- 6 - Strip
- 7 - Cable


VUE B






VUE C








VUE D




VUE E





VUE F




1



VUE G



VUE H



36

